

Installation Instructions for



Condu-Grip™

1. Cut ends of PE conduit / duct square
2. For ease of assembly chamfer the O.D. of each end of conduit



3. Place a mark on each end of conduit one half the length of the **Condu-Grip™** coupling
4. Insert ends of conduit through sealing o-ring of **Condu-Grip™**
5. Using strap or pipe wrench, twist **Condu-Grip™** in direction of **INSTALL** arrow while forcing both conduit ends into coupling to start threads.
6. Continue threading until mark is near edge of **Condu-Grip™**



Condu-Grip™ is designed for use on PE conduit, duct and innerduct only.

Manufactured By:



1-949-589-9360